

# Echologger MRS900

Ultra Compact Scanning Sonar



# Features

- High resolution sonar with real-time imaging
- One of the most compact scanning sonar in the world
- Low power consumption
- Digital CHIRP Technology
- No Wear/Tear Parts (Contactless Rotating Transformer Mechanism)
- Versatile connection scheme - Side or bottom
- Easy to use - just plug and play
- Easy to operate with user friendly GUI software
- Fully plastic version available (no corrosion) : MRS900S

# Applications

- Navigation for ROV/AUV
- Underwater Structure Monitoring
- Obstacle Avoidance
- Diver-held Sonar
- Search & Rescue Operations

# Specification

Pulse Type	Chirp, CW
Operating Frequency	~900kHz
Beam Pattern	Fanbeam (2.5°H /25°V)
Range	from 30cm, up to 60m
Range Resolution	7.5 mm @ 100kHz Sampling Frequency
Scanning Angle	Selectable up to 360°
Scan Angle Resolution:	0.1125°, 0.225°, 0.45°, 0.9°, 1.8°
Scan Speed:	4 sec / 360° @ 5 m, Scanning Resolution 0.9° 6.4 sec / 360° @ Range 10 m and Scanning Resolution 0.9° 40 sec / 360° @ Range 60 m and Scanning Resolution 0.9°
Transmit Pulse Length	500 us (chirp), 10 - 100us (CW)
Interface	RS232 / RS485 up to 1 Mbaud
Power Requirements	12 - 60 VDC, 4 W max
Cable max length	300m @ 2 Mbaud, 1 km @ 115,200 baud
Connector	MCIL6M(Subconn) or pigtail
Operating Depth	2000 m / 1000m(MRS900L) / 300m(MRS900S)
Material	Hard Anodize Aluminum(MRS900, MRS900L/ Acetal(MRS900S)
Dimensions(mm)	D66 x H76, D64,H75 (MRS900L), D64 x H80 (MRS900S)
Weight	MRS900 :580 / 350g (in air / in water) MRS900L : 410 / 190g MRS900S : 380 / 140g

## Echologger MRS900 vs. Tritech Micron sonar

	MRS900	Micron	Note
Frequency	900 kHz	700 kHz	
Pulse	Chirp (long range) CW (short range)	Chirp only	MRS transmits more sophisticated tailored pulses, ie., uses CW at short ranges and Chirp at long ranges
Pulse Length	CHIRP : 500μsec CW : 10~ 100μsec	200μsec	
Gain control	±15dB	NA	MRS can control signal gain
Beam angle	2°(H)/ 25°(V)	3°(H)/ 35°(V)	MRS has more resolution with sharper beams (2°)
Range	0.3 ~60m	0.3~75m	Micron covers longer range
Range resolution	Max 7.5mm	Max 7.5mm	Same
Scanning resolution	0.1125°, 0.225°, 0.45°, 0.9°, 1.8°	0.45°, 0.9°, 1.8°	MRS finer angular scanning resolutions (X4)

# Echologger MRS900 vs. Tritech Micron sonar

	MRS900	Micron Sonar	Note
Interface	RS232/RS485	RS232/RS485	Same
Comm. speed	115,200 ~ 921,600 & 1,00,0000 baud (Auto detection)	Max. 115,200 baud	MRS has a higher communication speed (X8)
Power supply	12 - 60 VDC 2W	12-48 VDC @ 4W	MRS has more flexible power supply range with less consumption (50%)
Connector	Side or Bottom	Side only	MRS has a connector either on the side or on the bottom
Depth rate	2,000m/1,000m/300m	750m	MRS can go deeper
Size	D66,H76/D64,H74 (L)/ D66,H80(S)	D56,H79	Micron is smaller in diameter, MRS is smaller in height
Weight	580g(350g water) 410g(190g water) : L 380 (140g water) : S	420g/(180g)	Similarly light

# Product Images



# Product Images



MRS900L



# Product Images





# Product Images



## Product Images



**NEW! : MRS900S**

## Product Images (with protection gear)



# Product Images





# Product Images





# Product Images





# Product Images






# Product Images



# Scanned Images






# Scanned Images



Range 10m






# Scanned Images




Range 30m



# Scanned Images



Range 60m





# Echologger MRS900

Ultra Compact Scanning Sonar

